Please be sure to read the enclosed Shark® Owner's Guide prior to using your unit.

804006406

Shark® ROTATOR® with Self-Cleaning Brushroll SPEED POWERED LIFT-AWAY®

QUICK START GUIDE

WHAT'S INSIDE

- Ⓐ Vacuum Pod
- Ⓑ Motorized Floor Nozzle
- Ⓒ Handle & Hose
- Ⓓ Wand
- Ⓓ Pet Multi Tool
- Ⓔ Pet Power Brush
- Ⓖ Crevice Tool

ASSEMBLY



Attach onboard accessories

TIPS



Slide hose clip into back of wand for convenience.

For quick cord access, rotate upper hook down and remove cord.

To store your vacuum, wrap cord around cord hooks.

MAINTENANCE

Empty the dust cup after each use.



TIP:
Rinse foam and felt filters every 3 months, and HEPA filter every year.
Rinse filters with water only and allow them to air-dry completely.
Tap loose dirt from foam filters as needed between washes.
Note: The foam filter may discolor over time. This is normal.

Self-Cleaning Brushroll

The self-cleaning brushroll automatically removes hair wrap. If some hair or debris remains after continued use, remove the cover to access the brushroll.



Using a coin, turn locks counterclockwise to open, then lift off cover to access brushroll.

Clear blockages from airway.



Replace cover, pressing down firmly on all sides before turning locks clockwise to close.

Note: The images shown here are for illustrative purpose only and may vary.

2 WAYS TO CLEAN

UPRIGHT



Floor Setting
Slide the Floor Selector up or down to choose floor type.

Suction Control
Slide to MIN to increase maneuverability on carpets. Slide to MAX for more suction on bare floors.

Power
Push the Power button to turn the vacuum on or off.

LIFT-AWAY®



Lift-Away Release
Press release button to lift pod off nozzle.



Handle Release

OR

Wand Release

Attach accessories to handle or wand.

804006406

PRINTED IN MEXICO Elbrd: Y.T.
OBPN: ZU621_QSG_MP_Mv1_191204
SC: 04-15-2021_1P MODEL: ZU621_B